TH 991

RIC STRIKE

TEMPLATE: 639335

REV. 1

4/10/24

6300 SERIES EXIT DEVICES USING SNB SEX NUTS:
USE 3/8" DRILL PULL SIDE
USE 9/32" DRILL PUSH SIDE MACHINE SCREWS: WOOD SCREWS: USE 5/32" DRILL MACHINE SCREWS: USE #7 OR 13/64" DRILL AND 1/4-20 TAP 6. MINIMUM STILE WIDTH: 4 1/2" 5. CHECK PDQ WEBSITE FOR MOST RECENT REVISION WWW.PDQLOCKS.COM 4. DIMENSION "X" SIZED FOR DOOR.
REFER TO DEVICE INSTRUCTIONS
WHEN CUTTING DOWN FOR 1. VERIFY PRINTED TO SCALE NOTES: 3. SEE TRIM TEMPLATE (IF APPLICABLE) FOR RELATED MACHINING DETAILS 2. SEX NUTS MAY BE REQUIRED FOR UNREINFORCED DOORS OR **USE #25 OR 5/32" DRILL AND #10-24 TAP** STRIKE DEVICE COMPOSITE FIRE DOORS.
CONSULT DOOR MANUFACTURER'S
RECOMMENDATIONS NARROWER OPENING FINISHED FLOOR [1016] 40" **ACCESS HOLE** Ø3/4" WIRE 5/8" OR SURFACE MOUNT FASTENERS ∞ 1 3/8" THIS SIDE ON FRAME STOP THIS SIDE ON DOOR (2 15/16" BACKSET WITH 5/8" STOP, 1/8" DOOR GAP & 1/16" DOOR BEVEL) **FOLD HERE** 2 1/2" TO STOP \oplus \oplus 3/8" ()RHR DOOR VERIFY THESE AGAINST 3/8" DEEP PUSH SIDE TRIM TEMPLATE Ø5/8" **UP FOR** MODIFIED TO FIT — HIS SIDE UP FOR (SEE NOTE #4) THIS SIDE "X" CAN BE FOR ELECTRIFIED Ø1/2" PUSH SIDE 3/8" – **OPTIONS** \oplus 2230 Embassy Dr. Lancaster, PA 17603 PDQ Manufacturing LHR DOOR help@pdqlocks.com www.pdqlocks.com 717-656-4281